


LCD Controller Operation Instructions

Picture for keys




BUTTON	DESIGNATION	OPERATION
	Power	Press to power on or off the heat pump
	Up/Down	Press to set desired water temperature
	Speed	Press to switch between Smart and Silence mode Smart mode: 100%-20% Silence mode: 80%-20%
	Mode	Press to shift among Auto, Heating and Cooling.
	Time/Timer	Setting time and timing

Note:

- ✧ You may set the desired water temperature from 18 to 40°C.
- ✧ The  on the right shows the inlet water temperature. The  on the left shows the outlet water temperature.

- ✧ After you turn on the heat pump, the fan will start to run in 3 minutes. In another 30 seconds, the compressor will start to run.

Symbols on the Controller

- ✧  Auto Mode  Defrost Mode
- ✧  Heating Mode  Cooling Mode
- ✧  Timer ON/OFF

Time setting

- ✧ Press  for 5 seconds to enter time setting. 88:88 is flashing on the display
- ✧ Press  and  to adjust the time (fast adjusting by continuous pressing).
Then, press  to confirm and exit.
- ✧ In the time setting mode, if no operation for 30 seconds, the previous pressing will be lost and exit automatically.

Timer on and off

- ✧ Press the  for 10 seconds to enter the timer setting. The “ON” will be flashing to enter the Timer ON setting. Press the  and  to adjust Timer ON time. You can choose Timer on (Display: ON), or Repeat Timer ON (Display: 1 ON) by pressing . Then press  to confirm
- ✧ When the “ON” stops flashing, and “OFF” is flashing, you enter the Timer OFF mode. Press the  and  to adjust Timer OFF time. You can choose Timer OFF (Display: OFF), or Repeat Timer OFF (Display: 2 OFF) by pressing . Then press  to confirm

- ✧ After entering the Time ON/OFF setting, press  directly without adjusting the time to cancel the relevant Timer setting.
- ✧ Exit automatically if no operation for 30 seconds in the Timer ON/OFF mode.

Mode Selection

- ✧ The Smart mode as default will be activated when the device is tuned on. And the controller shows “”.
- ✧ When the device is on, press “” button to enter the Silence mode. “” will be light. Press “” again to switch to Smart mode.

Compulsory Defrosting Operation

- ✧ When the machine is on heating and the compressor is working continuously for 10 minutes, press both “” and “” buttons for 5 seconds to start compulsory defrost. (Note: the break between compulsory defrost needs to be more than 30 minutes.)
- ✧ The symbol of defrost is twinkling when machine is compulsory or auto defrost.
- ✧ The period and ending of compulsory defrost is the same as auto defrost.